



iPhone 6s Plus Pentalobe Screws Replacement

Replace or remove the P2 Pentalobe screws in an iPhone 6s Plus.

Written By: Evan Noronha



INTRODUCTION

Follow this guide to replace or remove the P2 Pentalobe screws in your iPhone 6S Plus.



TOOLS:

- [P2 Pentalobe Screwdriver iPhone](#) (1)
-

Step 1 — Pentalobe Screws



 Before disassembling your iPhone, discharge the battery below 25%. A charged lithium-ion battery can catch fire and/or explode if accidentally punctured.

- Power off your iPhone before beginning disassembly.
- Remove the two 3.4 mm Pentalobe screws on either side of the Lightning port.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-09-19 09:29:05 AM.